

2060 HF Telephone interconnect - base station package
2060 HF Telephone interconnect - base station package

Part Number	Packaging Type	Net Weight	
BC20601	SC3	8.15 kg	

Features:-

- Full 16 digit dialling access from "Telcall" equipped HF Mobiles and remote base stations
- Access to 98 telephone numbers, pre-programmed in the 2060 Telephone interconnect, for 4 and 6 digit selcall equipped HF Mobiles and remote base stations
- Remote logging and supervisory functions using its internal modem and the supplied desktop PC modem card and 2060 Remote supervisory software



BC20600



BC205000



BC202200



BCM20600


Note:- See brochure for more detailed information.



BCA20602



BCA90021



BCA20019



BCUSB20601

Includes:-

2060 Telephone interconnect	BC20600			
2050 HF Transceiver fitted with Selcall, Telcall and RS-232 Control option	BC205000			
2022 Mains power supply	BC202200			
3U Side - plate pack	BCA20019			
2060 Remote supervisory software	BCUSB20601			
2060 Remote supervisory software connecting cable	BCA20602			
2060 Operation and installation manual	BCM20600			
Interface cable to connect 2061 to 2050 Transceiver	BCA90021			

2060 HF Telephone interconnect

2060 HF Telephone interconnect

Part Number	Packaging Type	Net Weight	
BC20600	C2	2.30 kg	

Features:-

- Full 16 digit dialling access from "Telcall" equipped HF Mobiles and remote base stations
- Access to 98 telephone numbers, pre-programmed in the 2060 Telephone interconnect, for 4 and 6 digit selcall equipped HF Mobiles and remote base stations
- Remote logging and supervisory functions using its internal modem and the supplied desktop PC Modem card and 2060 Remote supervisory software



BC20600



BCA90021



SA-09093



BCA20602



BCUSB20601



BCM20600

Note:- See brochure for more detailed information.

Includes:-

2060 Telephone interconnect	BC20600			
Interface cable to connect 2060 to 2050 Transceiver	BCA90021			
Telephone cable (2 metres) with RJ-45 Connectors	SA-09093			
2060 Remote supervisory software	BCUSB20601			
2060 Remote supervisory software connecting cable	BCA20602			
2060 Operation and installation manual	BCM20600			